

# Service Manual

**6M60-TL Diesel Engine** 

## **6M6**

### (for industrial use)

## **Shop Manual**

### diesel engine

#### **FOREWORD**

This Shop Manual is published for the information and guidance of personnel responsible for maintenance of the Mitsubishi 6M60-TL series diesel engine, and includes procedures for adjustment and maintenance services.

We earnestly look forward to seeing that this manual is made full use of in order to perform correct services with no wastage.

For more details, please consult your nearest authorized Mitsubishi forklift truck dealer.

Kindly note that the specifications and maintenance service figures are subject to change without prior notice in line with improvement which will be effected from time to time in the future.

SEPTEMBER 2006

Applicable models 6M60-TL

#### **GROUP INDEX**

GENERAL	00
ENGINE	11
LUBRICATION	12
FUEL AND ENGINE CONTROL ELECTRONICALLY CONTROLLED	13A
FUEL SYSTEM	13E
COOLING	14
INTAKE AND EXHAUST	15
EMISSION CONTROL	17
ELECTRICAL	54
SPECIAL EQUIPMENT	61